


Assembly instructions:

Basket Columns for Smaller Pots

Item #ZBCSWB

Recommended for use with pots having a 12" or greater rim diameter



Components:

Please check that you have the following:

- 12" diameter Base Ring
- 40" column in two sections
- Hardware packet includes:
 - Spacer Washer 'B'
 - 2 x bolts (short and long)
 - 2 x split ring lock washers.
- 14" Pamela Crawford side planting basket with liner

Assembly — requires an adjustable wrench.

1. Choose a Flower Pot of at least 12" diameter at the rim, with a center drainage hole in the bottom.
2. Place the split ring lock washer on the long bolt.
3. Insert bolt and lock washer through Base Ring, through the drainage hole and through the Spacer Washer which you will place inside of pot.
4. Take the bottom column section that has the smaller welded plate and screw the column down onto the upward pointing bolt that is pointing up from the bottom of the pot, until the assembly is snug.
5. Slide the top column onto the bottom column.
6. Take the 14" basket and remove the liner. Insert the short bolt and washer through the bottom center hole of the basket and into the thread in the top of the Column. Tighten until snug. Replace the liner — and you're ready to plant — as described on the Basket Label.